
CONTROL BY WEB CONNECTIVIT-E GOLDEN RATIO SA











Unlimited Possibilities









ANALOG INPUTS

Pressure Sensor Frequency Sensor Wind Speed Sensor Flow Sensor

DIGITAL INPUTS

Switches Moisture Sensors Door Sensors Motion Detectors Window Sensors

Unlimited Possibilities







Remotely control and monitor up to 32 expansion modules and 128 ControlByWeb products via web browser for a tailored solution to your unique applications!






- STAND ALONE
- PEER TO PEER
- SLAVE DEVICES






UP TO 128 DEVICES & 1.024 I/O POINTS Expansion Module






STAND ALONE DEVICES




Unlimited Possibilities









REMOTE MANAGEMENT










CONNECTIVITY




EXAMPLES APPLICATIONS








CONTROL GARAGE DOOR




CONTROL GARAGE DOOR




STAND ALONE INPUT



X-600M controller with expansion modules or PLC




AT THE SAME NETWORK




ANALOG INPUT

Sensors: Flow Wind Speed Pressure Frequency




WEB REGISTERS




WEB REGISTERS






ANALOG INPUT


Sensors: Flow Wind Speed Pressure Frequency




TEMPERATURE CONTROL




REBOOT IP DEVICES





CONNECTIVITY: 2 STAND ALONE DEVICES
















DIGITAL INPUT





IRRIGATION








THERMOSTAT SENSORS





8 RELAY MODULE R-S


4 RELAYS STAND ALONE NC-NO-COM







REMOTE MANAGEMENT 16 RELAYS-16 INPUTS







$\boldsymbol{\times}$	X-332					
General Settings	Analog 1: 0.045	Sensor 1: ×	_	Count 1: 0		
	Analog 2: 0.048	Sensor 2: 🗙		Count 2: 0		
	Analog 3: 0.053	Sensor 3: 🗙				
1/0	Analog 4: 0.105	Sensor 4: 🗙				
Setup	Input 1: ON	Relay 1: ON	ON	OFF	PULSE	
	Input 2: OFF	Relay 2: ON	ON	OFF	PULSE	
	Input 3: OFF	Relay 3: ON	ON	OFF	PULSE	
OFF	Input 4: OFF	Relay 4: ON	ON	OFF	PULSE	
itor and ontrol	Input 5: OFF	Relay 5: ON	ON	OFF	PULSE	
	Input 6: OFF	Relay 6: OFF	ON	OFF	PULSE	
	Input 7: OFF	Relay 7: OFF	ON	OFF	PULSE	
	Input 8: OFF	Relay 8: OFF	ON	OFF	PULSE	
	Input 9: ON	Relay 9: OFF	ON	OFF	PULSE	
	Input 10: ON	Relay 10: ON	ON	OFF	PULSE	
	Input 11: ON	Relay 11: ON	ON	OFF	PULSE	
	Input 12: OFF	Relay 12: ON	ON	OFF	PULSE	
	Input 13: OFF	Relay 13: ON	ON	OFF	PULSE	
	Input 14: OFF	Relay 14: ON	ON	OFF	PULSE	
	Input 15: OFF	Relay 15: ON	ON	OFF	PULSE	
	Input 16: OFF	Relay 16: OFF	ON	OFF	PULSE	
	Input 17: OFF	extVar 1: ON	ON	OFF	0	SET
	Input 18: OFF	extVar 2: OFF	ON	OFF	0	SET
		extVar 3: OFF	ON	OFF	0	SET
		extVar 4: OFF	ON	OFF	0	SET
		extVar 5: OFF	ON	OFF	0	SET
		Wed, 03 Apr 20	13 12:30	:21		



REMOTE MANAGEMENT



3.071 CORRECTING WWW.GomGrolByWeb.com .324 .000 .097 .000 .097 .000 .097 .000 .097 .0000 .0000 .000 .000 .000



DIMENSIONS





GROUP OF CBW



